



PHOENIX FENCE

■ EDMONTON

12816-156 STREET T5V 1E9
PHONE: (780) 447-1919
FAX: (780) 447-2512
TOLL FREE: 1-800-661-9847

□ CALGARY

6204-2nd STREET S.E. T2H 1J4
PHONE: (403) 259-5155
FAX: (403) 259-2262
TOLL FREE: 1-888-220-2525

Installation Guidelines for Pave Over/Trenched In Style Flexible Loops:

Gravel Driveways:

- Layout loop location. Closest edge of loop to be minimum 6' from gate.
- Trench using a trenching machine or backhoe 18" deep for the loop area including the lead wire back to the gate operator location.
- Place 2 to 3" of sand in the bottom of the trench for the loop area and compact (not required for the lead wires).
- Place loop in trench, run lead wires (twisted pair) back to gate operator using 1/2" pvc conduit ensure to cement the joints.
- Cover loop area in trench with 2 to 3" of sand and compact.
- Backfill trench for loop area and lead in wire. Ensure no large rocks crush the loop or conduit when backfilling.
- Connect twisted pair lead wires to loop detector in gate operator as per the instructions for the loop detector.